

EURO ECO / EURO deluxe

DC 2

ellard



DC 2 - Control Unit
conforms to DIN EN 12453



Installation Manual


Connection

1-phase 230VAC motor




remove bridge when
installing build-in-starters


connection for build-in-starters



Turn power on Checking




green light on ●




● red light off


ready to operate



running up




stop




running down




door position up



middle



door position down




turn power off 😊


[illegible][illegible][illegible]

11


Program II





keypad




external timer




green light




transponder





light
on




radio control




Program I




on






8,2k Ω




no testing




testing active




GB




3 sec.




2 min.




prewarning in-active




prewarning active



geba article
505.LS4E.OL



NC





Turn power on

Checking


 green light on

turn power off ☺


Program




8,2k Ω




CT closing
time off 




CT closing
time on 




CT closing time
30 sec. 






CT closing time
120 sec. 




go function off




go function active




 ight
prewarning in-active



 ight
prewarning active



testing in-active



testing active

Turn power on
ready to operate.

The door control DC 2 EURO is designed for hold to run control of power operated doors. The basic version is designed for hold to run operation only, and you are not allowed to use the automatic function without using additional safety devices.

- In case of using DC 2 EURO with a permanent mains connection, an all-pole main switch with an appropriate back-up fuse must be provided.
- Before operation, check whether the permissible mains voltage range of the device corresponds to the local mains voltage.
- Please note that the door control as well as the motor are for indoor installation only.
- During installation, initial operation, maintenance and testing of the DC 2 EURO it is necessary to observe the safety and accident prevention regulations valid for the specific application. Only trained electrical craftsmen should work on electrical equipment.

Appliance according to the regulations

The door control DC 2 EURO is provided for the operation of sectional-, rollershutter-, folding- and swingdoors. The manufacturer of the complete installation is responsible. He must take care that the relevant standards and guidelines (e.g. DIN 1986, EN 12050) have to be respected.

He must take care that a technical documentation of the whole installation is made available.

The technical documentation must be added to the door unit.

Installation, operating and use of the unit against this manual or the described technical specifications causes danger for persons and produces a liability- and obligations release.










National and regional precautions and standards for the installation, as well as safety precautions of local technical standards have to be respected.

Technical data		
Model	DC 2 – EURO deluxe	DC 2 – EURO ECO
Supply voltage	230VAC 4,5VA	230VAC 4,5VA
Frequency	50 Hz	50 Hz
Protection class	IP 54	IP 54
Outputs motor	3x NO relay contact 230 V / 5 A 2x NO relay contact 230 V / 2 A 1x unregulated supply voltage 24V DC, max. 50mA	3 x NO relay contact 230 V / 5 A 1x unregulated supply voltage 24V DC, max. 50mA
Wiring	1,5 mm ² max.	1,5 mm ² max.
Operating temperature	- 10 C° to + 55 C°	- 10 C° to + 55 C°

Table of contents

Security instructions and technical data	p2
DC – 2 EURO ECO	
<i>1-phase 230VAC motor and build-in-starters</i>	p3
<i>Layout</i>	p4
<i>Programming</i>	p5
<i>Optional programming radio control</i>	p6
<i>Troubleshooting</i>	p7
DC – 2 EURO deluxe	
<i>1-phase 230VAC motor and build-in-starters</i>	p3
<i>Layout</i>	p8
<i>Status display</i>	p9
<i>Programming</i>	p10-11
<i>Troubleshooting</i>	p12
Connection and Accessories for DC – 2 EURO ECO and DC – 2 EURO deluxe	
<i>Limit switches</i>	p13
<i>KDT 2 / M-Series 2T and KDT 3 Pushbutton</i>	p14
<i>M-Series 1T, emergency stop / KDT 1 and ES Series</i>	p15
<i>J-Series and J-Series with Stop</i>	p16
<i>LS 1 and LS 2 Photobeams</i>	p17
<i>Safety-edge Pro-Sec-O</i>	p19
Connection and Accessories for DC – 2 EURO deluxe only	
<i>LS 2 and LS 3 Reflector</i>	p18
<i>LS 4 Photobeam and 8k2 Ω resistor</i>	p19
<i>Signal light 230VAC and Court light 230VAC</i>	p20
<i>Cody wiring and programming</i>	p21-22
<i>Transponder wiring and programming</i>	p23-24
<i>Radio control programming</i>	p25-26

troubleshooting


Status Display			Status red LED	Beep	Action to take
	Security 		Off	No	1, 2, 3, 4
	 Safety edge active		Off	No	1, 2, 3
	 Safety edge damaged		On	Yes	7
	 Photobeam active		Off	No	1, 2, 3
	 Photobeam damaged		On	Yes	8
	Relais damaged		On	Yes	5
	RT ⌚ error		On	Yes	1, 2, 3
	Safety top barrier active		Off	No	1, 2, 3
	Safety top barrier damaged		On	Yes	10
	No Power		Off	No	1, 9
1	control installation		6	change module	
2	control DIP-switch position		7	change safety edge	
3	control pre-wired electrical bridges		8	change photobeam	
4	control limit switches		9	change fuse	
5	contact dealer		10	change the safety top barrier	

troubleshooting



Status red LED		action to take	
1 x		1, 2, 3	
 Safety edge active		1, 2, 3	
2 x		1, 2, 3, 7	
 Safety edge damaged		1, 2, 3, 7	
3 x		1, 2, 3	
Security 		1, 2, 3	
4 x		1, 2, 3	
RT ⌚ error		1, 2, 3	
Off		1,9	
No power		1,9	
1	control installation	6	change module
2	control DIP-switch position	7	change safety edge
3	control pre-wired electrical bridges	8	change photobeam
4	control limit switches	9	change fuse
5	contact dealer	10	change the safety top barrier

Connection

Limit Switch open
Limit Switch open
Limit Switch close
Limit Switch close
Prelimit Switch
Prelimit Switch





No Limit Switches
(bridged!)




remove bridges when
installing build-in-starters

Limit Switch open
Limit Switch open
Limit Switch close
Limit Switch close
Prelimit Switch
Prelimit Switch





Connection accessories

KDT 3 Pushbutton





KDT 2 Pushbutton / M-Series 2T





remove bridge when
installing KDT 3 Pushbutton

M-Series 1T






Emergency Stop / KDT 1




remove bridge

ES Series





Photobeams

LS 1




LS 2





remove bridge

LS 2 Reflector





LS 3 Reflector





remove bridge

Court light (230 VAC) / Signal light






DC 2 – EURO deluxe

Signal light (230 VAC)




J-Series



remove bridge when
installing J-Series with Stop



J with Stop





Optional accessories for DC2 deluxe

Cody

1. Wiring
Keypad





2. DIP-switch / Program 2
Programming mode on





3. Insert Codes (10 different Codes with 4 or 5 digits) programming

Insert Code (e.g.)	Confirm	Status Display	Beep
1234			____ _
78541			____ _
5398			____ _
...			

LS 4





8k2



☐	☐	☐	☐	☐	☐	☐	On
☐	☐	☐	☐	☐	☐	☐	Off
1	2	3	4	5	6	7	

8,2kΩ

Safety-edge Pro-Sec-O




☐	☐	☐	☐	☐	☐	☐	On
☐	☐	☐	☐	☐	☐	☐	Off
1	2	3	4	5	6	7	

Safety edge

Transponder


1. Wiring









2. DIP-switch / Program 2 Programming mode on

■	□	□	□	□	■
1	2	3	4	5	6

On
Off



3. Programming max. 10 different Keys

	Key Nr.	position
	↠ 1	
	↠ 2	
	↠ 3	
Maximum 10 Keys		

4. Programming mode off

☒	☐	☐	☐	☐	☐	On
1	2	3	4	5	6	Off



5. Cancel Keys

☒	☐	☐	☐	☐	☐	On
1	2	3	4	5	6	Off

press micro push-button to choose

press micro push-button two seconds

key canceled / position free



Radio control (maximum 20 Transmitters)


1. Plug in the RC Module



2. DIP-switch / Program 2 programming mode on

				■	
■	■	■	■	■	■
1	2	3	4	5	6

On
Off




3. Programming




press one button for two seconds


(or another transmitter)




and so on. Maximum 20 Transmitters.



= 10



= 11



= 12 and so on.

4. Programming mode off

				■	
■	■	■	■	■	■
1	2	3	4	5	6

On
Off



5. Cancel Transmitters

				■	
■	■	■	■	■	■
1	2	3	4	5	6


On
Off

press micro push-button to choose


8

press mirco push-button two seconds


transmitter canceled / postion free



The door control DC 2 EURO is designed for hold to run control of power operated doors. The basic version is designed for hold to run operation only, and you are not allowed to use the automatic function without using additional safety devices.




remove bridge marked with 
when installing build-in-starters



remove bridge marked with 
when installing build-in-starters

Radio control (maximum 20 Transmitters)**1. Plug in the RC Module****2. Programming mode on**
Press button >5 seconds
red LED flashes fast**3. Programming**

Press one button for two seconds
red LED flashes long once = stored
(or another type of transmitter)
and so on. Maximum 20 Transmitters.

**4. Programming mode off**

10 seconds after the last programming the programm returns to standart mode.

5. Cancel all Transmitters

Press button >5 seconds
red LED flashes fast
press button once more for >5 seconds
red LED off = all transmitters cancelled

